



BELMONT ARBOR

GENERAL INFORMATION




Please see back side for contents.

Suggested tools NOT included


- Wood Stakes (4)
- Step Ladders (2)
- Rubber hammer
- String Line
- Level
- Pencil
- Tape Measure
- Stool or short ladder
- Shovel
- Tube of Vinyl Glue

Assembly Instructions



DISCLAIMER: This product is designed to be used solely and exclusively as a decorative object. It should not be intended for playing or climbing.


For Assembly Instructions and warranty information please read QR code with cell phone or visit:
<http://azemblaofamerica.com/pvc-arbor/>




Important: check the inside of posts for materials.

Content


- | | |
|---------------------------------|--------------------------------------|
| [A] Top panel long spindles (3) | [G] Double snap pins (33) |
| [B] Beams (2) | [H] Posts (4) |
| [C1] Top panel middle rails (3) | [i1] Side panel middle rails(4) |
| [C2] Top panel middle rails (2) | [i2] Side panel middle rails(8) |
| [D] Vertical caps end caps(6) | [J] Side panel vertical spindles (6) |
| [E] Beam end caps (4) | [K] Slide buttons (8) |
| [F] Post end caps (4) | |



[K]




[G]




[E]




[B]



[F]



[H]



[D]




[C]

Arbor Assembly

check the inside of posts for materials.

POST 1

- (A) Top panel long spindles without holes (3)
- (C1) Top panel middle rails with holes (3)
- (C2) Top panel middle rails (2)
- (F) Post end caps (4)
- (E) Beam end caps (4)
- (D) Vertical caps end caps(6)



POST 2

- (B) Beams (2)



POST 3

- (ii) Side panel middle rails(2)
- (i2) Side panel middle rails(4)
- (J) Side panel vertical spindles (3)

POST 4

- (ii) Side panel middle rails(2)
- (i2) Side panel middle rails(4)
- (J) Side panel vertical spindles (3)


First step Main Frames Assembly



The holes must be located towards the interior of the frame.

1- Place the posts (H) and fit the beam (B) as shown in the diagram above

2- Repeat the process with the next beam (B) and the remaining posts (H)




Arbor Assembly


Second step Upper panel Assembly

3- Locate the (G) snaps (9) and profiles (A) (3) inside post 1

insert the snaps (G) into the profile (A)




4- Take out the (C2) (2) without holes, C1 (3) and unite them with the (A) profile (3).




Arbor Assembly

Third step Side panels Assembly


5- Locate the (G) snaps (24) and (J) profiles (6), (i2) profiles (8) inside post 3 and 4
insert the snaps (G) into the profile (J)



6- Take out the (i2) profile (4) and unite them with the (J) profile (3).





7- Repeat the process with the next profile (i2) profile (4) and (J) profile (3).




Arbor Assembly

8- Locate the (K) buttons (8) and (i1) profiles (4), inside post 2 and 3

insert the (K) buttons (2) into the (i1) profile




9- Top off the side panels with (i1) profiles (2) from the extremes.




Arbor Assembly

Final Assembly

10- Place the posts and the beams and fit the side panels and top panel as show in the drawing.





11-note that II shall cross Beam (k).



13- Raise up the Arbor and apply vinyl glue to the inside of the end caps and attach them to the profiles as shown. Hold the end cap in place for 30 seconds to allow the glue to dry.


12- Fit the profiles on the side panels and top panel.



INSTALLATION INSTRUCTIONS ARBOR



OPTION 1

GROUND INSTALLATION



1- Measure and mark the location of the post with a string. Adjust the string lines accordingly. Dig 4 holes 10" x 10" by 11 3/8" deep.

2- Insert the Arbor in the holes. Carefully move the arbor back into position and level it both vertically and horizontally.




INSTALLATION INSTRUCTIONS ARBOR

OPTION 2


CONCRETE INSTALLATION

1- Measure and mark the location of the post with a string. Adjust the string lines accordingly. Dig a hole 10" diameter by 17" deep.



2- Pour the concrete mixture in the holes.

3- Install the arbor and level before the concrete dries. Carefully move the arbor back into position and level it both vertically and horizontally.



4- Place supports that have a 4" height.

